







NO.	DESCRIPTION	CODE	QTY.
1	OIL RESERVOIR	RCP-01	1
2	OIL GAUGE	RF-11	1
3	M8 X 35 SCREW	32C-02	4
4	PUMP ASS'Y (65 THRU 100)	RCP-02	1
5	GASKET (A)	RCP-03	1
6	MAIN BASE	RCP-04	1
7	W-14 SI SEAL WASHER	RB-09	1
8	AIR VENT	13S-21	1
9	P-9 O-RING (A)	RF-38	1
10	M3 X 6 SCREW	13S-23	2
11	AIR VENT NUT	13S-24	1
12	M5 X 22 SCREW	RF-07	8
13	M3 FLAT WASHER	16-38	6
14	M3 X 10 SCREW W/LOCK WASHER	RCP-05	1
15	OS17233 OIL SEAL	RB-10	1
16	GASKET (B)	RCP-06	1
18	M4 X 25 SCREW	E3-100	3
19	M4 X 10 SCREW	R351-08	2
20	M4 FLAT WASHER	16-18	2
21	M2.3 X 25 SCREW	ROB-86	2
22	RELEASE UNIT	RCP-08	1
23	M2.3 HEX NUT	P500-22	2
24	SKB-2M SK BINDER	HR-30	1
25	MOTOR	RCP-09	1
26	M6 X 20 SCREW	RF1-02	4
27	M3 X 5 SCREW W/LOCK WASHER	RCP-10	7
28	M4 FLAT WASHER	E3-101	11
29	M4 LOCK WASHER	410-07	8
30	M4 X 8 SCREW	RA-19	8
31	UNIT BOX (1)	RCP-11	1
32	CONTROL UNIT	RCP-12	1
33	UNIT BOX (2)	RCP-13	1
34	M2.6 X 5 SCREW (T.P.)	RCP-14	8
35	M3 X 5 SCREW (T.P.)	ROB-94	8
36	WIRE (RED)	RCP-15	1

NO.	DESCRIPTION	CODE	QTY.
37	M3 X 8 SCREW (T.P.)	RCP-16	8
38	SOCKET	RCP-17	4
39	CONTACT HOUSING	RCP-18	2
40	CONTACT BLOCK	RCP-19	2
41	WIRE (BLACK)	RCP-20	1
42	WIRE (YELLOW)	RCP-21	1
43	M5 X 18 SCREW	RC33-03	3
44	M5 X 10 SCREW	Y30-01	4
45	STOPPER PLATE	RCP-22	2
46	BATTERY BRACKET	RCP-23	1
47	M5 X 10 SCREW	RF1-01	4
48	PUMP COVER	RCP-24B	1
49	M3 X 10 SCREW (T.P.)	HR-24	4
50	BATTERY RETAINER	RCP-25	2
51	M3 LOCK WASHER	5N-61	4
52	SWITCH BASE	RCP-26	1
53	RECEPTACLE	RCP-45	1
54	LED LAMP	RCP-46	1
55	MAIN SWITCH	RCP-47	1
56	SWITCH ASS'Y	RCP-27	1
57	M3 HEX. NUT	RA-21	3
59	M3 X 10 SCREW	E3-118	3



NO.	DESCRIPTION	CODE	QTY.
65	KEY (1)	RB-30	1
66	6 X 6 ROLLER	RB-31	6
67	KEY (2)	RB-32	1
68	ROTOR	RB-33	1
69	VANE CAP	FF-14	1
70	SUCTION JOINT	RCP-28	1
71	P-8 O-RING	85-34	2
72	SUCTION PIPE	RCP-29	1
73	STRAINER	RF-25	1
74	DRUM	RB-35	1
75	BEARING PLATE AS-1106	RB-36	2
76	NEEDLE THRUST BEARING	RB-37	1
77	CAM ASS'Y	RF-26	1
78	1/4" BALL	26-22	2
79	SPRING (70)	RB-44	2
80	CYLINDER ASS'Y	RB-46A	1
82	SPRING HOLDER	RB-48	6
83	SPRING (4)	16-48	6
84	3/16" BALL	16-49	6
85	CHECK VALVE (1)	RB-47	1
86	P-7 O-RING	16-60	5
87	P-7 BACK-UP RING (B.C.)	RB-49	2
88	CE-10 SNAP RING	40-16	2
89	HIGH PRESSURE PIPE	RCP-30	1
90	LOW PRESSURE PIPE	RB-53	1
91	3 X 18 DRIVE PIN (AW)	RF-33	1
92	PT 1/8" SCREW	RB-55	1
93	BASE	RF-32	1
94	7/32" BALL	16-26	3
95	BALL HOLDER	RB-58	1
96	SPRING HOLDER (1)	RB-57	1
97	M6 X 40 SCREW	RB-61	7
98	M6 X 80 SCREW	E3-77	4
99	COPPER GASKET (4)	26-20	1
100	STOPPER SCREW	RB-60	1
101	MICRO SWITCH A-20GQ-B	RCP-31	1

NO.	DESCRIPTION	CODE	QTY.
102	ADJUSTING SCREW	RCP-32	1
103	SPRING (632)	RCP-33	1
104	PUSH PIN	RCP-34	1
105	M3 X 4 SCREW (F.P.)	RCP-35	1
106	HOLDER	RCP-36	1
107	P10A BACK-UP RING (B.C.)	RB-66	1
108	P-10A O-RING	RB-65	1
109	P-2 BACK-UP RING (B.C.)	RCP-37	1
110	P-2 O-RING	RCP-38	1
111	PLUG	RCP-39	1
112	M5 X 5 SCREW (F.P.)	510A-05	2
113	VALVE BODY	RCP-40	1
114	SPRING (76)	16-39	1
115	9/32" BALL	16-40	1
116	M10 X 12 SCREW (F.P.)	40-47	1
117	P-3 O-RING	16-36	1
118	RELEASE PIN	ROB-79	1
119	5/32" BALL	22-21	1
120	MALE SWIVEL JOINT	RF-22	1
121	P-16 BACK-UP RING (B.C.)	22-24	2
122	P-16 O-RING	22-25	2
123	FEMALE SWIVEL JOINT	RF-24	1
125	JG-16 SNAP RING	RF-23	1
126	S-8 O-RING	R510A-08	1
127	LOCK NUT	RCP-41	1
128	SAFETY VALVE ASS'Y	RCP-42	1
129	M6 HEX. NUT	RCP-43	1
130	EXHAUST PIPE	RCP-44	1
131	SPRING (598)	R150-13	1
132	ADAPTER 3/8" PT-M 3/8" NPT-F	P85-80	1
133	FEMALE COUPLER	FC-8/DP-8	1