



Huskie
TOOLS

MODEL SP-20

Parts List

NO.	DESCRIPTION	CODE	QTY.
1	SHOULDER BOLT	16-03B	4
2	HEAD SHEAR	20-02	1
3	SLIDE PIN	20-71	1
4	SPRING (144)	85-37	1
5	SPACER	20-70	1
6	MAIN HEAD	20-04	1
7	M6 LOCK WASHER	16-02	4
8	M6 HEX. NUT	16-01	4
9	CE-8 SNAP RING	16-09	4
10	PIN (46)	16-10	2
11	LATCH	16-11	1
12	M5 X 8 SCREW (C.P.)	P55A	1
13	BODY HEAD	20A-01	1
14	BLADE	20-07	1
15	SPRING (78)	P20-01	1
16	BLADE SCREW	16-19	1
17	RAM	P20-02	1
18	P-25 BACK-UP RING (B.C.)	P20-03	1
19	P-25 O-RING	P20-04	1
20	CYLINDER	P20A-01	1
21	3/8" NPT-NPT NIPPLE	3/8X3/8FF	1
22	MALE COUPLER	MC-8/DC-8	1